

Log at position A to record the energy demands for the whole premises.

Record at B to know the demand by sub-board A.

Record at C to measure lighting demands.

Record at the various points to know each machine's demands.

